

Europa Components, Europa House, Airport Way, Luton, Beds, LU2 9NH  
 Technical: 01582 692 444 | [technical@europacomponents.com](mailto:technical@europacomponents.com)  
 Sales: 01582 692 440 | [sales@europacomponents.com](mailto:sales@europacomponents.com)  
 Website: [www.europacomponents.com](http://www.europacomponents.com)



It is the responsibility of the person installing the electrical equipment to ensure that the installation meets the requirements of the IET wiring regulations and is therefore 'fit for purpose'. Factors such as correct selection of components, cable sizing, protective devices and Earth bonding are all critical and should be checked prior to full testing and power-up. Any other regulations applicable to the equipment being installed such as the Machinery Directive and current health and safety legislation must also be adhered to.

All connections (including factory made) must be checked for the correct tightness prior to commissioning of the electrical installation.  
 All connections should be inspected periodically to ensure correct tightness.



**DO NOT USE POWER TOOLS ON THESE PRODUCTS**

## Part Number: **ATLAS-SOP-POST-XX** **Pole Mounting Kits for ATLAS Enclosures**

### Includes

- 2x Stainless Steel Mounting Brackets
- 2x Stainless Steel Cable Tie
- 4x M6 x 25mm Panhead Screws
- 4x Flat Washers
- 4x Spring Washers
- 4x M6 Hex Nuts




### Features & Benefits

- All-in-one kit - no additional parts required.
- No drilling required reducing installation time.
- Long stainless steel cable tie accommodates a wide range of pole diameters (maximum pole diameter 220mm).
- Stainless steel bracket and straps provides corrosion resistance.


### Part Numbers

Pole Kits	Enclosures (Including "-P" Versions)
ATLAS-SOP-POST-X3	ATLAS-302514    ATLAS-403020 ATLAS-803020
ATLAS-SOP-POST-X4	ATLAS-404020    ATLAS-504020 ATLAS-604023
ATLAS-SOP-POST-X5	ATLAS-605023
ATLAS-SOP-POST-X6	ATLAS-806030



### Fitting Instructions

**ATLAS-SOP-POST-X3**



**ATLAS-SOP-POST-X4**



**ATLAS-SOP-POST-X5**



**ATLAS-SOP-POST-X6**

