


### ⚠ Important Safety Notice ⚠


It is the responsibility of the person installing the electrical equipment to ensure that the installation meets the requirements of the IET wiring regulations and is therefore 'fit for purpose'. Factors such as correct selection of components, cable sizing, protective devices and Earth bonding are all critical and should be checked prior to full testing and power-up. Any other regulations applicable to the equipment being installed such as the Machinery Directive and current health and safety legislation must also be adhered to. Terminals, including factory fitted, should be checked periodically to ensure correct tightness.

**DO NOT USE POWER TOOLS ON THESE PRODUCTS**


| Product Prefix             | Blue & White Handle   | Red & Yellow Handle | Shaft Section (mm) | L (mm)  | P (mm)                | S (mm) | D (mm)  |
|----------------------------|-----------------------|---------------------|--------------------|---------|-----------------------|--------|---------|
| Standard Handle and Shafts |                       |                     |                    |         |                       |        |         |
| LBF125/LBFD125             | LBPHBW100             | LBPHRY100           | □7                 | 250     | 165-282               | 94     | 45      |
| LBF160/LBFD160             | LBPHBW020             | LBPHRY020           | □10                | 227     | 180-292               | 115    |         |
| LBF200/LBFD200             |                       |                     |                    |         |                       |        |         |
| LBF315/LBFD315             | LBPHBW040             | LBPHRY040           | □14                | 239     | 216-286               | 176    |         |
| LBF400/LBFD400             |                       |                     |                    |         |                       |        |         |
| LBF630/LBFD630             | LBPHBW050             | LBPHRY050           |                    | 186     | 235-286               | 60     |         |
| LBF800/LBFD800             |                       |                     |                    |         |                       |        |         |
| Extended Shafts            |                       |                     |                    |         |                       |        |         |
| Product Prefix             | Extended Shaft Type 1 | Shaft Section (mm)  | L (mm)             | P (mm)  | Extended Shaft Type 2 | L (mm) | P (mm)  |
| LBFD125                    | LBES020               | □7                  | 387                | 165-419 | Not Available         |        |         |
| LBFD160                    | LBES030               | □10                 | 375                | 180-440 | LBES040               | 536    | 180-601 |
| LBFD200                    |                       |                     |                    |         |                       |        |         |
| LBFD315                    | LBES050               | □14                 | 345                | 216-392 | LBES060               | 535    | 216-582 |
| LBFD400                    |                       |                     |                    | 235-445 |                       |        | 235-635 |
| LBFD630                    |                       |                     |                    |         |                       |        |         |
| LBFD800                    |                       |                     |                    |         |                       |        |         |



P=DISTANCE FROM THE BACK OF THE SWITCH TO THE INSIDE OF THE PANEL



L=SHAFT LENGTH



S=HANDLE LENGTH